




SOFI




CZ: NÁVOD K OBSLUZE
DE: BEDIENUNGSANLEITUNG
EN: USER MANUAL
ES: MANUAL DE USO
FR: GUIDE D'UTILISATION
IT: ISTRUZIONI PER UTENTE
PL: INSTRUKCJA OBSŁUGI
RO: MANUAL DE UTILIZARE
SK: NÁVOD NA POUŽITIE

CZ: Cestovní postýlka
DE: Reisebett
EN: Travel cot
ES: Cuna de viaje
FR: Le lit de voyage
IT: Lettino da viaggio
PL: Łóżeczko turystyczne
RO: Pătuț pliabil
SK: Cestovná postieľka



A.



B.




C.



1.



2.



3.



4.




5.



6.




7.




8.



9.



10.



11.




12.




13.




14.



15.



16.



17.

Dear customer!

Thank you for choosing a product by Kinderkraft. Our designs are child-oriented – safety and quality always comes first, stay comfortable knowing that you have made the best choice.

„IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY“

SAFETY INSTRUCTIONS AND PRECAUTIONS

WARNING

- Be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the cot;
- Do not use the product if any part is broken, torn or missing and use only spare parts approved by the manufacturer;
- Do not leave anything in the cot or place the cot close to another product, which could provide a foothold or present a danger of suffocation or strangulation, e.g. strings, blind/curtain cords;
- Product is ready for use, only when the locking mechanisms are engaged. Check carefully that they are fully engaged before using the folding travel cot.
- A mattress designed exclusively for use with this product is included. The mattress dimensions 920 x 510 mm provide fitting and safety of the child.
- All assembly elements and fittings should be tightened properly and checked regularly and retightened as necessary.
- Accessories which are not approved by the manufacturer shall not be used.
- To prevent injury from falls, if the child is able to climb out of the cot, the cot shall no longer be used for that child.

Additional warning for the BABY COT function:

WARNING

- Do not use more than one mattress in the cot.
- Only use the mattress sold with this cot, do not add a second mattress on this one, suffocation hazards.

- The lowest position of the base is the safest. When the child starts sit alone is advised to use only this base level.
- If you leave the child in the cot unattended, always check, if the side entrance is fastened with a zip.

Additional warning for the PLAY PEN function:

- **WARNING** Do not place the playpen close to an open fire or other heat source.
- **WARNING** Do not use the playpen without the base/mattress.
- **WARNING** Ensure that the playpen is fully erected and all the locking mechanisms engaged before placing your child in this playpen.
- The bottom of the pen must be mounted at the lowest level.
- The playpen is designed for children up to 36 months weighing up to 15 kg.

1. List of travel cot elements:

- A. Cot frame with the cover
- B. Mattress
- C. Bag

2. Assembly:

Undo the zip fastener on the bag (C) and remove the baby cot (FIG. 1). To unfold the baby cot grasp the frame (A) on both sides, and then pull it up until the supports are unfolded (Fig. 2). NOTE! To ensure safety, make sure that the supports are unfolded properly and locked. If the mattress (B) is not fastened, it should be fixed inside the cot using the zip fastener (FIGS. 3, 4 and 5) and secured with a clamp (FIG. 6). To fold the cot, it should be turned in such a way that the supports face up (FIG. 7). Pull one support holding the frame with your leg (FIG. 8), and then lower it down inside the cot (FIGS. 9 and 10). Repeat the same operation for the other support (FIG. 11).

3. Travel cot functions:

Rocking function: The baby cot has a rocking function. To use it, slightly raise the baby cot on one side (FIG. 12), and then unlock the rockers turning them out (FIGS. 13 and 14). Repeat the same operation with the other rocker. NOTE! While unlocking the rockers, the child cannot be placed inside the baby cot!

Base adjustment: The baby cot has base height adjustment. To lower the base unclip the zip fastener fixing clamp and open the zip fastener inside the baby cot (FIG. 15). Place the mattress inside the cot in the bottom position (FIG. 16). When the mattress is at the lowest level, you can use the side entrance by undoing the zip fastener (FIG. 17).

NOTE! In the baby cot function the upper mattress position is designed for children who cannot yet sit up alone. In the playpen function, the mattress must always be in the lowest position.

4. Maintenance and claining:

Travel cot cover - wipe clean with a mild soap and water. Never clean with abrasive, ammonia based, bleach based or spirit type cleaners. The travel cot must be dried thoroughly before use or storage.

Mattress cover - Wash at max. 30°C, do not bleach, do not dry in a tumble dryer, do not iron, do not dry clean.

Frame - clean the frame with a soft, clean and damp cloth using mild soap.



VÝROBCE/HERSTELLER/MANUFACTURER/FABRICANTE/FABRICANT/
FABBRICANTE/PRODUCENT/PRODUCĚTOR/VÝROBCA:

4Kraft Sp. z o.o.
ul. Tatrzańska 1/5
60-413 Poznań, Poland